

ESSENTIAL CONTROLS

Driving with a clear windscreen is essential when driving; and of course during a Driving Test. This guide is designed to cover all the demister and windscreen controls. You may be asked to explain who you would achieve this during the 'show me, tell me' section of your test - which may require you to switch on the ignition.

THE IGNITION



Important

- Press the button **WITHOUT** the clutch down to activate the ignition (to use the electrics)
- Press the button **WITH** the clutch down to start the engine

Don't forget to check that the hand brake is on and that the gear selector is in neutral BEFORE starting the engine!

FRONT WIPERS



Push down for a quick wipe

- **1 click down** for a quick wipe (wipers will not stay on)

All 'on' settings are up

- **1 click up** for intermittent / automatic (*the dial in the middle adjusts the time between the wipes*)
- **2 clicks up** for normal speed
- **3 clicks up** for fast

REAR WIPER



Press gently to turn on

Press gently to turn off

Rear Wiper

The rear wipers are activated by the small button on the end of the stalk. One click for intermittent, two clicks for 'on'. Be careful as this switch is very sensitive.

DEMISTER CONTROLS



Fully Automatic Setting

There are various settings to adjust the demisters for both the front and rear windows. However the 'MAX' setting activates the front & rear window demisters simultaneously. When you press the button again, the front and rear heaters will stay on a little longer and will turn off automatically.

Try using the control without taking your eyes off the road!